




	1-Trash Met		2-Latin Kit		3-Funk Kit		4-Jazz Kit		5-Speed Met	
BD1	030	BASIC BD	001	18PER S	003	20DW S	005	20LUD S	028	POW3 BD
BD2	030	BASIC BD	001	18PER S	003	20DW S	005	20LUD S	028	POW3 BD
SD-Head	039	14LUD S	031	10PER S	043	14SON S	051	14TAM S	043	14SON S
SD-Rim	076	POP RS	079	PER RIM	079	PER RIM	077	DW RIM	079	PER RIM
SD-RS	042	14LUD RS	034	10PER RS	046	14SON RS	054	14TAM RS	046	14SON RS
T1-Head	097	14SON S	081	10DW S	085	10SON S	087	12DW S	095	14DW S
T1-Rim	000	EMPTY	228	AGO H	000	EMPTY	000	EMPTY	000	EMPTY
T2-Head	097	14SON S	081	10DW S	085	10SON S	087	12DW S	096	14DW H
T2-Rim	194	DUCK	195	COWBEL	195	COWBEL	195	COWBEL	195	COWBEL
T3-Head	099	16DW S	081	10DW S	085	10SON S	088	12DW H	095	14DW S
T3-Rim	000	EMPTY	227	TAMBO H	000	EMPTY	000	EMPTY	000	EMPTY
T4-Head	101	16SON S	081	10DW S	085	10SON S	087	12DW S	095	14DW S
T4-Rim	198	TIM H	000	EMPTY	000	EMPTY	000	EMPTY	000	EMPTY
CR-Head	133	17SAB TS	133	17SAB TS	133	17SAB TS	133	17SAB TS	129	17PAI TS
CR-Bell	134	17SAB TH	134	17SAB TH	134	17SAB TH	135	17SAB B	131	17PAI B
CR-Edge	136	17SAB C	136	17SAB C	136	17SAB C	136	17SAB C	132	17PAI C
RD-Head	121	21MEI TS	121	21MEI TS	121	21MEI TS	121	21MEI TS	121	21MEI TS
RD-Bell	123	21MEI B	123	21MEI B	123	21MEI B	123	21MEI B	123	21MEI B
RD-Edge	124	21MEI C	124	21MEI C	124	21MEI C	124	21MEI C	124	21MEI C
AUX1-Head	133	17SAB TS	132	17PAI C	133	17SAB TS	133	17SAB TS	129	17PAI TS
AUX1-Bell	135	17SAB B	134	17SAB TH	135	17SAB B	132	17PAI C	131	17PAI B
AUX1-Edge	136	17SAB C	136	17SAB C	136	17SAB C	136	17SAB C	132	17PAI C
AUX2-Head	133	17SAB TS	132	17PAI C	133	17SAB TS	133	17SAB TS	129	17PAI TS
AUX2-Bell	135	17SAB B	135	17SAB B	135	17SAB B	135	17SAB B	131	17PAI B
AUX2-Edge	136	17SAB C	136	17SAB C	136	17SAB C	136	17SAB C	132	17PAI C
HH-Head	164	S HO	164	S HO	164	S HO	164	S HO	180	P HO

	6-Pop Rock		7-Classic JZ		8-RNB Kit		9-Classic RK		10-Studio Kit	
BD1	013	22TAM S	009	22LUD S	011	22PER S	008	22SON H	017	24SON S
BD2	013	22TAM S	009	22LUD S	011	22PER S	007	22SON S	017	24SON S
SD-Head	063	14PDP S	059	14PER S	035	14DW S	055	14REM S	059	14PER S
SD-Rim	079	PER RIM	078	LUD RIM	078	LUD RIM	076	POP RS	079	PER RIM
SD-RS	066	14PDP RS	062	14PER RS	038	14DW RS	058	14REM RS	062	14PER RS
T1-Head	083	10TAM S	109	12GRE S	091	12SON S	103	18LUD S	093	13SON S
T1-Rim	000	EMPTY	000	EMPTY	000	EMPTY	250	User20	000	EMPTY
T2-Head	083	10TAM S	109	12GRE S	091	12SON S	107	12LUD S	093	13SON S
T2-Rim	109	12GRE S	195	COWBEL	195	COWBEL	195	COWBEL	195	COWBEL
T3-Head	103	18LUD S	109	12GRE S	092	12SON H	103	18LUD S	101	16SON S
T3-Rim	000	EMPTY	000	EMPTY	000	EMPTY	000	EMPTY	000	EMPTY
T4-Head	103	18LUD S	109	12GRE S	091	12SON S	103	18LUD S	101	16SON S
T4-Rim	000	EMPTY	000	EMPTY	000	EMPTY	000	EMPTY	000	EMPTY
CR-Head	133	17SAB TS	129	17PAI TS	129	17PAI TS	129	17PAI TS	133	17SAB TS
CR-Bell	135	17SAB B	131	17PAI B	131	17PAI B	131	17PAI B	135	17SAB B
CR-Edge	136	17SAB C	132	17PAI C	132	17PAI C	132	17PAI C	136	17SAB C
RD-Head	121	21MEI TS	125	24PAI TS	125	24PAI TS	121	21MEI TS	121	21MEI TS
RD-Bell	123	21MEI B	127	24PAI B	127	24PAI B	123	21MEI B	123	21MEI B
RD-Edge	124	21MEI C	128	24PAI C	128	24PAI C	124	21MEI C	124	21MEI C
AUX1-Head	133	17SAB TS	129	17PAI TS	129	17PAI TS	129	17PAI TS	133	17SAB TS
AUX1-Bell	135	17SAB B	131	17PAI B	131	17PAI B	131	17PAI B	135	17SAB B
AUX1-Edge	136	17SAB C	132	17PAI C	132	17PAI C	132	17PAI C	136	17SAB C
AUX2-Head	133	17SAB TS	129	17PAI TS	129	17PAI TS	129	17PAI TS	133	17SAB TS
AUX2-Bell	135	17SAB B	131	17PAI B	131	17PAI B	131	17PAI B	135	17SAB B
AUX2-Edge	136	17SAB C	132	17PAI C	132	17PAI C	132	17PAI C	136	17SAB C
HH-Head	164	S HO	172	Z HO	164	S HO	172	Z HO	164	S HO

	11-Big Power		12-70s Rock		13-Soul Kit		14-Garage Kit		15-Reggae Kit	
BD1	021	22PORK	015	24LUD S	021	22PORK	026	POW1 BD	022	20PEARL
BD2	019	26LUD S	000	EMPTY	021	22PORK	026	POW1 BD	022	20PEARL
SD-Head	055	14REM S	067	14YAM S	073	MAR SD	071	POWER S	075	ROCK SD
SD-Rim	078	LUD RIM	078	LUD RIM	079	PER RIM	077	DW RIM	077	DW RIM
SD-RS	058	14REM RS	070	14YAM RS	076	POP RS	072	POWER H	077	DW RIM
T1-Head	089	12TAM S	109	12GRE S	114	PER T1	119	LUD T1	089	12TAM S
T1-Rim	000	EMPTY	000	EMPTY	000	EMPTY	120	LUD T3	000	EMPTY
T2-Head	089	12TAM S	109	12GRE S	115	PER T2	118	LUD T2	089	12TAM S
T2-Rim	195	COWBEL	195	COWBEL	195	COWBEL	195	COWBEL	195	COWBEL
T3-Head	089	12TAM S	109	12GRE S	115	PER T2	120	LUD T3	089	12TAM S
T3-Rim	195	COWBEL	000	EMPTY	000	EMPTY	000	EMPTY	000	EMPTY
T4-Head	089	12TAM S	109	12GRE S	117	PER T4	120	LUD T3	120	LUD T3
T4-Rim	195	COWBEL	000	EMPTY	000	EMPTY	000	EMPTY	000	EMPTY
CR-Head	129	17PAI TS	129	17PAI TS	133	17SAB TS	129	17PAI TS	133	17SAB TS
CR-Bell	131	17PAI B	131	17PAI B	135	17SAB B	131	17PAI B	135	17SAB B
CR-Edge	132	17PAI C	132	17PAI C	136	17SAB C	132	17PAI C	136	17SAB C
RD-Head	125	24PAI TS	121	21MEI TS	125	24PAI TS	121	21MEI TS	125	24PAI TS
RD-Bell	127	24PAI B	123	21MEI B	127	24PAI B	123	21MEI B	127	24PAI B
RD-Edge	128	24PAI C	124	21MEI C	128	24PAI C	124	21MEI C	128	24PAI C
AUX1-Head	129	17PAI TS	130	17PAI TH	133	17SAB TS	129	17PAI TS	133	17SAB TS
AUX1-Bell	131	17PAI B	131	17PAI B	135	17SAB B	131	17PAI B	135	17SAB B
AUX1-Edge	132	17PAI C	132	17PAI C	136	17SAB C	132	17PAI C	136	17SAB C
AUX2-Head	129	17PAI TS	129	17PAI TS	133	17SAB TS	129	17PAI TS	135	17SAB B
AUX2-Bell	131	17PAI B	131	17PAI B	135	17SAB B	131	17PAI B	135	17SAB B
AUX2-Edge	132	17PAI C	132	17PAI C	136	17SAB C	132	17PAI C	137	16ZIJ C
HH-Head	164	S HO	164	S HO	164	S HO	164	S HO	164	S HO

	16-House Kit		17-Drum Kit		18-Elec Dance		19-March Band		20-Melody Kit	
BD1	025	BOX3 BD	011	22PER S	027	POW2 BD	029	JAZZ BD	023	BOX1 BD
BD2	025	BOX3 BD	024	BOX2 BD	027	POW2 BD	029	JAZZ BD	023	BOX1 BD
SD-Head	205	ESD 2	186	CONL O	204	ESD 1	048	14GRE M	032	10PER M
SD-Rim	078	LUD RIM	188	CONH T	077	DW RIM	079	PER RIM	079	PER RIM
SD-RS	205	ESD 2	185	CONH M	205	ESD 2	049	14GRE H	034	10PER RS
T1-Head	208	ETOM 2	196	TIM L	215	E PEC1	106	8DW H	212	9S 77
T1-Rim	000	EMPTY	198	TIM H	000	EMPTY	000	EMPTY	000	EMPTY
T2-Head	208	ETOM 2	191	BONH O	215	E PEC1	105	8DW S	212	9S 77
T2-Rim	199	WHISTLE	195	COWBEL	195	COWBEL	195	COWBEL	195	COWBEL
T3-Head	208	ETOM 2	192	BONL O	215	E PEC1	105	8DW S	212	9S 77
T3-Rim	000	EMPTY	190	TAMBO M	000	EMPTY	000	EMPTY	000	EMPTY
T4-Head	208	ETOM 2	197	CONL T	215	E PEC1	105	8DW S	212	9S 77
T4-Rim	000	EMPTY	183	CLAP	000	EMPTY	000	EMPTY	000	EMPTY
CR-Head	129	17PAI TS	129	17PAI TS	128	24PAI C	133	17SAB TS	133	17SAB TS
CR-Bell	131	17PAI B	131	17PAI B	131	17PAI B	135	17SAB B	135	17SAB B
CR-Edge	132	17PAI C	132	17PAI C	132	17PAI C	136	17SAB C	136	17SAB C
RD-Head	121	21MEI TS	121	21MEI TS	125	24PAI TS	121	21MEI TS	121	21MEI TS
RD-Bell	123	21MEI B	123	21MEI B	127	24PAI B	123	21MEI B	123	21MEI B
RD-Edge	124	21MEI C	124	21MEI C	128	24PAI C	124	21MEI C	124	21MEI C
AUX1-Head	129	17PAI TS	129	17PAI TS	129	17PAI TS	133	17SAB TS	133	17SAB TS
AUX1-Bell	131	17PAI B	131	17PAI B	131	17PAI B	135	17SAB B	135	17SAB B
AUX1-Edge	132	17PAI C	132	17PAI C	132	17PAI C	136	17SAB C	136	17SAB C
AUX2-Head	130	17PAI TH	129	17PAI TS	129	17PAI TS	133	17SAB TS	133	17SAB TS
AUX2-Bell	131	17PAI B	131	17PAI B	131	17PAI B	135	17SAB B	135	17SAB B
AUX2-Edge	132	17PAI C	132	17PAI C	132	17PAI C	136	17SAB C	136	17SAB C
HH-Head	172	Z HO	164	S HO	164	S HO	164	S HO	164	S HO