




Assembly Instructions Of Expansion




Major Expansion Ports



Only have drum head sound for expanded drum.




Only have surface sound for expanded cymbal.




* Drum / Cymbal tones can be adjusted individually if drum and cymbal are expanded from major expansion ports.


Secondary Expansion Ports



Only have drum head sound for expanded drum.



Only have surface sound for expanded cymbal.



* Drum / Cymbal will share the same tone with drum rim of connected drum if they are expanded from secondary expansion ports.